

EX600(103Key)/(MS-1636)

EX601 (88Key) / (MS-1636)

Key Parts	Part Name & Part Number	Description	Remark
MAIN BOARD / SUB PC BOARD ▲TOP			
	MODEM MA560-6 MDC1.5 S52-2801150-Q09	AZALIA MODEM CARD RoHS	
	MAIN Board 607-16361-030	MS-16361 10	
	USB Board 607-163502-B10	MS-163502 0B	
	TOUCHPAD MODULE S78-3700210-SD2	TM61PDZG307 79.7*47.7mm	

	<p>Touch board</p> <p>607-1636B-01S</p>	<p>MS-1636B 10</p>	
	<p>BlueTooth Board</p> <p>605-6837D-050</p>	<p>MS-6837D 10</p>	
	<p>WIRELESS MODULE</p> <p>S57-3800010-T46</p>	<p>TWINHAN AW-GE780</p> <p>WLAN 802.11b/g</p>	
	<p>Switch Board</p> <p>607-1636A-01S</p>	<p>MS-1636A 10</p>	
	<p>CMOS CAMERA MODULE</p> <p>S1F-0001100-AF5</p>	<p>1.3M Pixels/ACME/</p> <p>901-0001-11</p>	
<p>CPU </p>			

	<p>INTEL CORE 2 DUO 2.0 GHz</p> <p>A09-2020186-IX6</p>	<p>INTEL CORE 2 DUO T7300</p> <p>L2 Cache 4MB / FSB:800</p>	
	<p>INTEL CORE 2 DUO 2.4 GHz</p> <p>A09-2620126-I06</p>	<p>INTEL CORE 2 DUO X7800</p> <p>L2 Cache 4MB / FSB:800</p>	
	<p>INTEL CORE 2 DUO 2.0 GHz</p> <p>A09-2420116-I06</p>	<p>INTEL CORE 2 DUO T7700</p> <p>L2 Cache 4MB / FSB:800</p>	
	<p>INTEL CORE 2 DUO 2.2 GHz</p> <p>A09-2220106-I06</p>	<p>INTEL CORE 2 DUO T7500</p> <p>L2 Cache 4MB / FSB:800</p>	
	<p>INTEL CORE 2 DUO 2.0 GHz</p> <p>A09-2020166-I06</p>	<p>INTEL CORE 2 DUO T7300</p> <p>L2 Cache 4MB / FSB:800</p>	
	<p>INTEL CORE 2 DUO 1.8 GHz</p> <p>A09-1820176-I06</p>	<p>INTEL CORE 2 DUO T7100</p> <p>L2 Cache 2MB / FSB:800</p>	
<p>MEMORY ▲TOP</p>			
	<p>A-DATA 1GB DDR2 667</p> <p>S78-2408240-A97</p>	<p>A-DATA CHIP</p> <p>A-DATA/ADOPE1A16332</p>	
	<p>TRANSCEND 1GB DDR2 667</p> <p>S7C-S346201-T10</p>	<p>HYNIX CHIP</p> <p>TRANSCEND/TS128MSQ64V6J</p>	

	TRANSCEND 1GB DDR2 667 S78-2408123-T10	ELPIDA CHIP TRANSCEND/TS128MSQ64V6J	
	TRANSCEND 1GB DDR2 667 S7C-S346C01-T10	RJETRAM CHIP TRANSCEND/JM488Q643A-6	
	TRANSCEND 1GB DDR2 667 S7C-S346801-T10	SAMSUNG CHIP TRANSCEND/TS128MSQ64V6J	
	TRANSCEND 512MB DDR2 667 S78-2407431-T10	HYNIX CHIP TRANSCEND/TS64MSQ64V6M	
	TRANSCEND 512MB DDR2 667 S78-2407330-T10	HYNIX CHIP TRANSCEND/TS64MSQ64V6J	
	TRANSCEND 512MB DDR2 667 S78-2407334-T10	ELPIDA CHIP TRANSCEND/TS64MSQ64V6J	
	TRANSCEND 512MB DDR2 667 S7C-S336C01-T10	RJETRAM CHIP TRANSCEND/JM467Q643A-6	
	TRANSCEND 512MB DDR2 667 S7C-S336801-T10	SAMSUNG CHIP TRANSCEND/TS64MSQ64V6J	
	TRANSCEND 1GB DDR2 533 S7C-S336801-T10	ELPIDA CHIP TRANSCEND/TS128MSQ64V5J	
	TRANSCEND 512MB DDR2 533	ELPIDA CHIP	

	S78-2407243-T10	TRANSCEND/TS64MSQ64V5J	
	TRANSCEND 512MB DDR2 533 S78-2407241-T10	ELPIDA CHIP TRANSCEND/TS64MSQ64V5J	
	APACER 1GB DDR2 667 S78-2408101-A42	ELPIDA CHIP APACER/78.02G63.423	
	APACER 512MB DDR2 667 S78-2407311-A42	ELPIDA CHIP APACER/78.92G63.421	
	APACER 1GB DDR2 533 S78-2408091-A42	ELPIDA CHIP APACER/78.02G51.423	
	APACER 512MB DDR2 533 S78-2407301-A42	ELPIDA CHIP APACER/78.92G51.421	
	TWINMOS 1GB DDR2 667 S7C-S346202-T75	HYNIX CHIP TWINMOS8D-A3KN5MHBTP	
	TWINMOS 512MB DDR2 667 S7C-S336201-T75	HYNIX CHIP TWINMOS/8D-A3JN5MHATP	

MIDDLE COVER



Hinge Cover Assy

S7C-S336201-T75


MS16323 Channel 103key





UPPER CASE ▲TOP			
	Top Case Assy 307-632C219-H74	MS1034 Channel 103key	Color:Black
	Top Case Assy 307-631C51A-TA2	MS1034 Channel 87key	Color:Black(Main)Silver(Second)
LOWER CASE ▲TOP			
	Low Case Assy 307-631D21A-H76	MS1636L1_Low Case ASSY	Color:Black
LCD Module ▲TOP			
	SAMSUNG 15.4 inch WXGA S78-2307073-S02	1280x800,ANTI-GLARE, SAMSUNG/LTN154X3-L01-H	
	LCD Bezel E2P-632B434-Y31	For 103key	Color:BLACK
	LCD Bezel	For 87key	Color:BLACK

	E2P-632B413-TA2		
	INVERTER S78-3300390-SG3	SAMPO/YIVNMS0020D11	
	INVERTER S78-3300341-S49	INVERTER/O2MICRO IC	
	INVERTER S78-3300350-SG3	SAMPO/YIVNMS0018D11	
	LVDS COAXIAL CABLE K19-3036002-H58	MB-2*20pin LCD-30pin INVERTER 6P	
	LCD BRACKET E2M-6320723-Y28	SUS,239.6*13.7mm NB, FOR MS-1034L1	

	<p>LCD_HINGE_R</p> <p>E2M-6320212-CD8</p>		
	<p>LCD_HINGE_L</p> <p>E2M-6320312-CD8</p>		
	<p>LCD Cover Assy</p> <p>307-632A215-H74</p>	<p>MS1034 Channel 103key</p>	<p>Color:Black</p>
	<p>LCD Cover Assy</p> <p>307-632A517-TA2</p>	<p>MS1034 Channel 87key</p>	<p>Color:Black+silver</p>
	<p>LCD Cover FILM</p> <p>E2P-6323922-Y42</p>		
<p>OPTICAL DEVICE ▲TOP</p>			
	<p>HLDS/GCC-T10N</p> <p>S7D-1220004-H44</p>	<p>COMBO 8x/24x24x24x</p>	

	HLDS/GSA-T20N S7D-1270007-H44	SUPER MULTI	
	SONY NEC OPTIARC/CRX880A S7D-1220002-SI4	COMBO24X-CDR/ 8X-DVDRAM	
	SONY NEC OPTIARC/AD-7530B S7D-1270009-SI4	SUPER MULTI 8x±DVDR/ 5x-DVDRAM	
	ODD Bezel ASSY for combo 307-631F211-SE0		
BATTERY ▲TOP			
	6 Cell Battery Pack S9N-0364210-SB3	PANASONIC 10.8V,4800mAH	
	RTC Battery D06-0100300-K26	NO RECHARGEABLE 3V,220mAh	
HDD ▲TOP			

	<p>HITACHI 120GB</p> <p>S71-2412505-HX5</p>	<p>HTS541612J9SA00 5400RPM</p>	
	<p>WD 160GB</p> <p>S71-2416501-W36</p>	<p>WD1600BEVS,8M BUFFER,</p>	
	<p>WD 80GB</p> <p>S71-2408505-W36</p>	<p>WD800BEVS,8M BUFFER</p>	
	<p>TOSHIBA 160GB</p> <p>S71-2416504-T14</p>	<p>TOSHIBA/MK1637GSX</p>	
	<p>TOSHIBA 120GB</p> <p>S71-2412506-T14</p>	<p>TOSHIBA/MK1237GSX</p>	
	<p>TOSHIBA 80GB</p> <p>S71-2408507-T14</p>	<p>TOSHIBA/MK8037GSX</p>	
	<p>TOSHIBA 60GB</p> <p>S71-2406503-T14</p>	<p>TOSHIBA/MK6037GSX</p>	
	<p>FUJITSU 120GB</p> <p>S71-2412502-F06</p>	<p>FUJITSU/MHW2120BH</p>	
	<p>FUJITSU 100GB</p> <p>S71-2410504-F06</p>	<p>FUJITSU/MHW2100BH</p>	

	FUJITSU 80GB S71-2408503-F06	FUJITSU/MHW2080BH	
	FUJITSU 60GB S71-2406502-F06	FUJITSU/MHW2060BH	
	HDD Rubber E2Y-6110111-G40		Color:BLACK
	HDD Bracket Assy 307-6320112-Y28		
	CPU Thermal Module E32-0900482-L01	HEAT PIPE-2/MS-1636	
KEYBOARD ▲TOP			
	KeyBoard (US-International) S1N-3UUS121-C54	103KEY MP-03233U4-3596	Color:Black

	KeyBoard S1N-3UUS141-C54	103KEY MP-03233U4-359D	Color:Black
	KeyBoard S1N-2EUS121-C54	88KEY MP-03086U4-3599	Color:Black
	KeyBoard (Korean) S1N-3UKR621-C54	103KEY MP-03233K0-359H	Color:Black
	KeyBoard (Hebrew) S1N-3UHB111-C54	103KEY MP-03233HB-359D	Color:Black

ACCESSORIES [▲TOP](#)


	AC Adapter 90W,19V S93-0406090-L44	LI SHIN/SLS0202C19K25LF	
	AC Adapter 90W,19V OS9-1034020	EDAC/EA10953(312109512)	
	Power Cord (3 Pin) K33-3001020-I45	USA	

SCREWS TYPE [▲TOP](#)

	<p>Screw M2*L3mm</p> <p>E43-1203003-H29</p>		
	<p>Screw M3*L3.5 mm</p> <p>E43-1303501-H29</p>		
	<p>Screw M2.5*L3 mm</p> <p>E43-1253003-H29</p>		
	<p>Screw M2.5*L5 mm</p> <p>E43-1255001-H29</p>		
<p>CABLE TYPE ▲TOP</p>			
	<p>WIRELISS CARD</p> <p>S57-3800010-T46</p>	<p>TWINHAN/AW-GE780</p> <p>WLAN,802.11b/g,MINI-PCI</p>	

	<p>WIRELISS CARD</p> <p>S57-0800070-I06</p>	<p>INTEL PRO WIRELESS 3945ABG</p> <p>WLAN,802.11a/b/g</p>	
	<p>WIRELISS CARD</p> <p>S57-0800101-I06</p>	<p>INTEL/4965AGNMM1GN</p>	
	<p>WIRELISS CARD</p> <p>S57-0800104-I06</p>	<p>INTEL/4965AGNMM2GN</p>	
	<p>WIRELISS ANTENNA-R</p> <p>S79-1800260-H39</p>		
	<p>WIRELISS ANTENNA-R</p> <p>S79-1800270-H39</p>		
	<p>BLUETOOTH ANTENNA</p> <p>S79-1800280-H39</p>		

	<p>Touchpad FPC (To M/B)</p> <p>K1C-1012014-J36</p>		
	<p>Touchpad FPC (To Button)</p> <p>K1C-1012012-J36</p>		
	<p>Button Board Cable</p> <p>K1C-1006010-J36</p>		
	<p>USB Cable</p> <p>K10-3016005-H39</p>		
	<p>BlueTooth Cable</p> <p>K10-3008069-H39</p>		

	<p>RJ11 Cable</p> <p>K10-3002088-H39</p>		
<p>OTHERS ▲TOP</p>			
	<p>Speaker Module</p> <p>S33-2100230-F33</p>		
	<p>LCD Bezel Rubber</p> <p>E2Y-6320931-Y40</p>		
	<p>MAGNET</p> <p>E2Y-5210811-SF7</p>		
	<p>CARD READER RUBBER</p> <p>E2Y-6321311-Y40</p>		
	<p>TouchPad Mylar</p> <p>E2P-6321622-H48</p>		

	<p>Bottom Door</p> <p>307-631J201-Y31</p>		
	<p>HDD Door</p> <p>307-632K215-SE0</p>		
	<p>FRONT_BEZEL</p> <p>E2P-6310114-SE0</p>		
	<p>CD-ROM Bracket</p> <p>E2M-6321111-Y28</p>		
	<p>Touchpad Bracket</p> <p>E2M-6321914-Y28</p>		

	<p>CMOS_LENS</p> <p>E2P-6322812-H48</p>		
	<p>MSI B FACE LOGO</p> <p>E2Y-W003811-H48</p>		
	<p>LOGO PLATE</p> <p>E29-1022010-H48</p>		
	<p>LOGO RING</p> <p>E29-1022220-H48</p>		